

# GIANT NEOSTRACK



Quick Start Guide

快速使用说明书

快速使用説明書

Schnellstartanleitung

Guía de inicio rápido

Guide de démarrage rapide

クイックスタートガイド

빠른 시작 안내

Aan de slag

Instrukcja szybkiego uruchomienia



Download  
neotrack App



neotrack App web version  
**[www.neotrack.com](http://www.neotrack.com)**

neotrack App 中国在线版本  
**<http://china.neotrack.com>**

## 1 BACK / STOP ( )

- Press to return to the previous page or cancel an operation.
- When recording, press to pause recording. Press it again to stop recording.

## 2 OK / LAP ( )

- In Menu, press to enter or confirm a selection.
- In free cycling\*, press to start recording.
- When recording, press to mark the lap.

## 3 ON or OFF / BACKLIGHT ( )

- Press to turn the device on.
- Press and hold to turn the device off.
- Press to turn on/off backlight.

## 4 DOWN / MENU ( )














- In Menu, press to move down to scroll through menu options.
- In Meter view, press to switch meter screen page.
- In free cycling mode, long press to return to Main Menu.
- When recording, long press to enter into Shortcut Menu.
- Free cycling is a mode with no recording. neostrack syncs with the movement of bicycles. It starts when you start pedaling, allowing you to view real time data without recording.









## 5 UP ( )

- In Menu, press to move up to scroll through menu options.
- In Meter view, press to switch meter screen page.

## Icon Description

	Bike 1-7		Speed Sensor active / inactive		Log Record in Progress
	No Signal (not fixed)		Cadence Sensor active / inactive		Recording is paused
	Weak Signal (fixed)		Combo Sensor active / inactive		Current speed is faster/ slower than average speed
	Strong Signal (fixed)		Power Sensor active / inactive		
	Heart Rate Sensor active / inactive		Power Status		

# Getting Started

Before first use, please charge your device for at least 4 hours. To begin 1. Press  to turn on the device. 2. Press  to select the display language and press  to confirm the selection. 3. Device will search for satellite signals. 4. After GPS signal is fixed \*, ( → ) just ride on and enjoy your workout in free cycling mode, and to record, press .

\* To get GPS acquisition, please take the device to an open sky outdoor environment.






## Track

With Track feature, you can plan trip via neostrack App or web version, use pervious rides from History or download gpx tracks online.


### Plan Trip via Giant neostrack App or web version ([www.neostrack.com](http://www.neostrack.com))

1. Download neostrack app or web version. 2. Sign up / log in on neostrack app or web version. 3. Tap Plan Trip to start planing trip by putting pins on map or entering locations in the slide menu. 4. Download the planned trip to the device via Sync. 5. In the Main Menu, select Track > Route and select the planned track and press  to start following the track.

### From device History

1. In the Main Menu, select History > View to select the desired tracks. 2. Select Create Track 3. Enter a name of the track and press  to save it. 4. Press  to be back to the Main Menu. 5. Select Track > Route and select the saved track and press  to start following the track.

## From 3rd Party Websites

1. Download gpx files to your computer. 2. Use USB cable to connect the device to the computer. 3. Copy the gpx files from your computer and paste to the “Add Files” folder of the device. 4. Remove USB cable. 5. In the Main Menu, select Track > Route and press  to start following the track.

## Sync (WLAN)

### Sync Data to / from Giant neostrack App and web version

With the access to the internet, your neostrack computer automatically updates GPS data, uploads recorded tracks, downloads planned trips from app server and checks for available firmware update.

It is required to add your device to your Giant neostrack account before syncing data for the first time. To add. 1. Scan the QR code labeled on the device securing paperboard inside the box with your smartphone to download neostrack App. 2. After neostrack App is installed, please sign up for an account. 3. In the app, tap “Scan Now” to scan the same QR code labeled on the device securing paperboard to add its UUID to your neostrack App account (or go to neostrack: Menu > Setup>System>UUID). 4. If a “successfully added!” message pops up on the neostrack App, you have successfully added your device to your neostrack account. If not, please tap “Retry” to scan again or enter the 16 digit device UUID number on the back of your device manually.




To perform Sync, please first go to your device: Setup > Network > Connect to set a wireless network connection, then go to Sync in the main menu and let your computer smartly guide you through the syncing process.


- Firmware updates usually take longer to download and install, select NO if you prefer to update it on your next sync.

### Share Your Tracks via USB






1. Connect the device to your computer via USB cable. 2. Select fit files from Giant folder in the device. 3. Upload files to popular training sites including STRAVA, Training Peaks, Goldencheetah, Endomondo, Map My Ride, Fit track and many more.

## Reset Neostrack

Long press all three keys (  /  /  ) at the same time to reset the device.



## Specification

Item	Description
Display	2.6" FSTN positive transfective dot-matrix LCD
Physical Size	92.9 x 57 x 20.3 mm
Weight	78g
Operating Temperature	-10°C ~ 50°C
Battery Charging Temperature	0°C ~ 40°C
Battery	Li polymer rechargeable battery
Battery Life	30 hours with open sky
ANT+™	Featuring certified wireless ANT+™ connectivity. Visit <a href="http://www.thisisant.com/directory">www.thisisant.com/directory</a> for compatible products     
GPS	Integrated high-sensitivity GPS receiver with embedded antenna
BLE Smart	Bluetooth smart wireless technology with embedded antenna
Water Resistant	Withstand immersion in water up to 1meter for up to 30 minutes
Wireless Local Area Network	IEEE 802.11 b/g/n

## Sensor Pair

In the Main Menu, select Setup > Bike Data > Bike 1 > Sensors > Heart Rate, Speed, Cadence, Speed/CAD, Power >More>Rescan

### Note:

Please go to [www.giant-bicycles.com](http://www.giant-bicycles.com) > Support > Owners Manuals to download User's Manual.